

To Watch DVD in Sanctuary:

1. Turn Power ON by using the labeled power button mounted in the equipment cabinet. (top of cabinet)
2. Press MAIN button on touch panel mounted in equipment cabinet. This will activate touchscreen. A red dot helps to identify it.



3. Press **DVD** button. Do not hold down, press and release. **The system can take up to a minute to power up**, do not press buttons until you see something on the projector screen. When ready, the following screen will appear automatically.



4. Power up the DVD player by pressing the **open/close** button on the touch screen, insert your disk. To start the DVD, push the tray in. Normally the DVD will begin to play. If not, push the blue PLAY button OR the white SELECT button. Some DVDs may require you to make a **menu selection** from the screen. Use the UP/DOWN buttons to

make the selection – then press SELECT.

5. **Power up the audio.** Use the 2 sliders marked Video L and Video R at the right side of the audio controls. **They have red dots.** Pressing the gray rectangular button should make the red lights go off, indicating that the sound is on.

6. Adjust the volume level using the sliders marked **Video L and Video R.**



7.

IF THERE IS NO VIDEO, check the red light at the left end of the SWITCHER:



if the light is NOT LIT, press the gray button beneath it!

8. When movie is over, press the **open/close button** on the touch screen to eject. Remove your disk and close the tray.

9. Press **POWER OFF** button on video touch panel.

10. Turn Power OFF by using the labeled power switch mounted in the equipment cabinet. (top of cabinet)