

To Watch DVD in the Social Hall: ver 11/2015

1. Turn Power ON by using the orange labeled power switch mounted in the equipment cabinet. (top of cabinet)
2. Press MAIN button on touch panel mounted in podium. This will activate touchscreen.
3. The projector will power up, and the screen will deploy automatically.



4. Press the Blu ray icon to launch the DVD/CD player

Press the EJECT icon to open the tray. Insert your disk then press EJECT icon again to close tray.

1. Once the DVD has loaded, press the blue PLAY button at the bottom of the DVD screen
2. Adjust volume using the slider. Be sure the square white ON button is illuminated

3. IF you need the sound in the back half of the Social Hall, manually turn on the amplifier in the cabinet marked **SOCIAL HALL 2**

4. When movie is over, remove your disc by using the EJECT button.

5. Press **POWER OFF** button on touch panel. **Projector will power down and the screen will automatically retract.**

6. Turn Power OFF by using the labeled power switch mounted in the equipment cabinet. (top of cabinet)

